


TRÅDLÖSA, BATTERIFRIA TRYCKKNAPPAR

ECW4109RFH8

Tryckknapp svart, vertikal pil 868 MHz


- Ingen kabeldragning
- Inga batterier
- Montering i 22,5 mm hål eller fästörön
- Stort urval av färger och symboler



PRODUKTBESKRIVNING

Tack vare att det inte behövs någon kabeldragning och att det finns varianter med fästörön för panelfri fixering blir hanteringen enklare för både konstruktörer och operatörer.

Använd artikelnummermatrisen för att bygga ihop den produkt du behöver.



Skapat artikelnummer i matrisen betyder inte att produkten verkligen är tillgänglig.
Vänligen kontakta oss för kontroll.

;

TEKNISK DATA

IP-klass

IP66

Material Hus	Plast
Temperaturområde från	-25 °C
Temperaturområde till	70 °C



Installation tips

The wireless signal works at its best when the space is free between the receiver and the transmitter.
Eliminate as far as possible obstacles, mostly if they are metallic!

RRH8 (868MHz) and RRH9 (902MHz) receivers

Main features

Feature	Description
Receiver	Receiver of signal through the antenna
Transmitter	Transmitter of signal through the antenna
Power	Power of 100 mW
Frequency	868 MHz / 902 MHz
Range	Range of 100 m
Antenna	Antenna of 100 m
Antenna	Antenna of 100 m
Antenna	Antenna of 100 m
Antenna	Antenna of 100 m

NOTE: The receiver and transmitter must be installed in the same place. The receiver and transmitter must be installed in the same place. The receiver and transmitter must be installed in the same place.

ECW - METAL PUSHBUTTON

Metal - Flush Pushbuttons

Metal - Extended Pushbuttons

Metal - Ring Shrouded Pushbuttons

ECW - METAL PUSHBUTTON
PANEL FREE FIXING (example)

- SDN
- CH4
- CH3
- CH2
- CH1
- PRR

COMING

